
GLAZED UMBRIAN TERRACOTTA

	USE
Interior flooring and wall coverings	YES
Exterior flooring and wall coverings	NO (wall coverings only if protected)



INSTALLATION TIPS

- · The tiles must be installed on a dry, level, and compact screed. Rising humidity can cause stains on the surface;
- · Combine tiles from different boxes to distribute the shades and to avoid inadvertently creating spots of color.
- · Lay the tiles down while dry to verify the shape and flatness of the product.
- The selection of the type of adhesive must be compatible with the existing substrate. The recommended type is white class C2TE or C2TE S1;
- Apply the adhesive evenly on the screed using a wide-toothed trowel. Apply the adhesive to the back of the tiles as well.
- Position the tiles by hand without hammering them. We recommend leaving a thin gap 4 6 mm wide. (In the event that you mix multiple formats the gap will follow the regularity of the tiles following their natural fit);
- · Verify that the vertical and horizontal alignment of the tiles is correct;
- · Use the adhesive to even out the flatness (always keep the surface clean);
- · Wait until the adhesive is completely dry, depending on the drying time of the adhesive.

Follow the installation by grouting with cement-based grout - coarse grained (epoxy grout Is not recommended);

We also recommend to cut the tiles on the back (unglazed) side because the vibrations of the saw can chip the glazed surface of the product.

All video tutorials are available on: https://www.youtube.com/channel/UCdkyYRr9M4EhLvPEwqinvuA

RECCOMENDED MAINTENANCE

Routine cleaning (every day)

We recommend using the product FANGOROSA SOAP - universal daily cleaner for all surfaces. Alternatively, we recommend mild soap and water.

All products are available on www.fangorosa.com

